



Monkey Nuts™ V2

Sometimes combinations of tire and front derailleur can cause the tire and derailleur to overlap slightly. Monkey Nuts V2 hold your wheel farther back in the dropouts so the tire clears the front derailleur. They are designed to be secured onto the frame and left there, that's it. Simply sandwich the dropout with the Monkey Nuts, slide the Monkey Nuts all the way forward in the dropouts and cinch the bolt.

For more information about front derailleur/rear tire compatibility on Surly frames, go to surlybikes.com/fatbikes-front-derailleurs or contact us. For additional safety information surlybikes.com/safety.

