

Karate Monkey™ Spacers

Karate Monkeys are designed to be used with traditional-style front derailleurs (NOT top-swing). Due to KM's shorter chainstays, certain tires can rub on the derailleur cable fixing bolt. Use of the KM spacers will alleviate this issue. Remove QR skewer or axle nuts. Position spacers in dropout, with center hole in line with hub axle, with the tabs facing inboard and forward (washer side outboard). Position wheel all the way forward in the dropout. Replace skewer or axle nuts. Align and secure.

