

Chainring Guard Instructions

Hi there. Thanks for spending your hard-earned cash on this Surly product. Surly stuff is designed to be useful and durable. We're confident it will serve you well for years to come.

⚠WARNING: Cycling can be dangerous. Bicycle products should be installed and serviced by a professional mechanic. Never modify your bicycle or accessories. Read and follow all product instructions and warnings including information on the manufacturer's website. Inspect your bicycle before every ride. Always wear a helmet.

For additional safety information about all Surly products visit: surly bikes.com/safety

Chainring Guard Compatibility and Intended Use

The Surly Chainring Guard is designed for use with the Surly O.D. Crank. It is designed to work with chainrings up to a 30 tooth count.

Tools Required for Installation

- · Torque wrench
- Chainring nut wrench
- 5mm hex wrench
- Grease

Installation of the Chainring Guard

- 1. Remove crankset from bottom bracket.
- 2. Remove chainrings.
- 3. Clean crankarm and chainring bolts thoroughly.
- 4. Place the Surly Chainring Guard on the crank so the "inboard" side is facing the bike's frame.
- Apply grease to the threads of the chaining bolts provided. Insert the chaining bolts through the front of the crankarm holes and thread them into the Surly Chaining Guard. Alternately tighten them to 9Nm.
- Grease chainring bolts and install your Surly chainring to the inner crank bolt holes on the back of the crank arm (the 58 BCD holes).
 Make sure your chainring is properly oriented. Alternately tighten chainring bolts to 9Nm.



Ongoing Maintenance

Periodically check to make sure the chainring bolts are properly torqued.

Limited Warranty

This Surly product is warranted against defects in materials and workmanship for one year from the date of retail purchase of the product, subject to the limitations detailed below. Save your dated receipt for proof of purchase.

This warranty does NOT cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents
 or anything other than normal use
- · Installation of components, parts or accessories not originally intended for or compatible with Surly product as sold
- · Damage or deterioration to the paint, surface finish, aesthetics or appearance of the product
- Normal wear and tear
- · Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

This limited warranty is expressly limited to the repair or replacement of a defective product, at the option of Surly, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Surly product and is not transferable. This warranty applies only to products purchased through an authorized dealer or distributor. In no event shall Surly be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to our products except as set forth herein.

This limited warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This limited warranty does not affect your statutory rights.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The Web Address: surlybikes.com